

- 
1. 72-37033-3 ROD ASSEMBLY, RADIUS ARM
  2. 72-37015-1 FWD. BOMB DOOR LOCK
  3. ENGINE DRIVEN HYDRAULIC PUMP—PESCO 582-B-8
  4. ACCUMULATOR—VICKERS AA-14002-A
  5. RELIEF VALVE—AIR ASSOC. HC-2530-M2
  6. UNLOADING VALVE—VICKERS AA-14512
  7. FILTER-PURULATOR 26947-G 159J-12
  8. 73-82225 HYDRAULIC RESERVOIR
  9. 88-82205 FWD. CYLINDER, BOMB DOOR ACTUATING
  10. PRESSURE GAGE—AN-G-2 5771-4 OR AC94-27922-E4
  11. EMERGENCY SELECTOR VALVE—BENDIX 402941
  12. SHUT-OFF VALVE—BENDIX 402841
  13. HAND PUMP—AIR ASSOC. HC-1813-M3
  14. CHECK VALVE—BENDIX 40155, MODEL 2207-A4
  15. 88-31076 PEDESTAL ASSEMBLY, PILOT'S CONTROL
  16. 73-82206 AFT. CYLINDER, BOMB DOOR ACTUATING
  17. 72-37023 ARM ASSEMBLY, BOMB DOOR PISTON
  18. 72-37033-1 ROD ASSEMBLY, BOMB DOOR LINK
  19. 72-37021 ARM ASSEMBLY, BOMB DOOR ACTUATING
  20. 72-37015-2 AFT. BOMB DOOR LOCK
  21. 72-37033-3 ROD ASSEMBLY, RADIUS ARM
  22. 72-37033-2 ROD ASSEMBLY, BOMB DOOR LINK
  23. 72-37021 ARM ASSEMBLY, BOMB DOOR ACTUATING
  24. 72-37033-1 ROD ASSEMBLY, BOMB DOOR LINK
  25. 72-37023 ARM ASSEMBLY, BOMB DOOR PISTON
  26. CHECK VALVE—BENDIX 401561
  27. 88-82300 SELECTOR VALVE
  28. SHUTTLE VALVE—HOOF PRODUCT HL-794
  29. 72-37011 DOOR ASSEMBLY, LOWER BOMB
  30. 72-37010 DOOR ASSEMBLY, UPPER BOMB
  31. 72-37033-2 ROD ASSEMBLY, BOMB DOOR LINK

Figure 24—Bomb Doors Hydraulic System Diagram (Sheet 2 of 2)