




NATOPS FLIGHT MANUAL NAVY MODEL AV-8B/TAV-8B 161573 AND UP AIRCRAFT

THIS PUBLICATION SUPERSEDES NAVAIR
A1-AV8BB-NFM-000 DATED 15 MARCH 2008 AND
CHANGE 1 - 15 SEPTEMBER 2009.

THIS PUBLICATION IS INCOMPLETE WITHOUT
A1-AV8BB-NFM-400.



DISTRIBUTION STATEMENT C — Distribution authorized to U.S. Government Agencies only and their contractors to protect publications required for official use or for administrative or operational purposes only, 1 September 2011. Other requests for this document shall be referred to Commander, Naval Air Systems Command (PMA-257), 47123 Buse Rd, Bldg 2272, Patuxent River, MD 20670-1547.

DESTRUCTION NOTICE — For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

ISSUED BY AUTHORITY OF THE CHIEF OF NAVAL OPERATIONS AND
UNDER THE DIRECTION OF THE COMMANDER,
NAVAL AIR SYSTEMS COMMAND.

THE AIRCRAFT 1

INDOCTRINATION 2

NORMAL PROCEDURES 3

FLIGHT CHARACTERISTICS 4

EMERGENCY PROCEDURES 5

ALL-WEATHER OPERATION 6

COMMUNICATION PROCEDURES 7

WEAPONS SYSTEMS 8

FLIGHT CREW COORDINATION 9

NATOPS EVALUATION 10

PERFORMANCE DATA 11

INDEX & FOLDOUTS

