


NAVAIR 01-T34AAC-1



# NATOPS FLIGHT MANUAL NAVY MODEL T-34C AIRCRAFT

THIS PUBLICATION SUPERSEDES NAVAIR 01-T34AAC-1  
DATED 1 MARCH 1995 AND CHANGED 1 FEBRUARY  
1998.



DISTRIBUTION STATEMENT C — Distribution authorized to U.S. Government Agencies and their contractors to protect publications required for official use or for administrative or operational purposes only (1 January 1991). Other requests for this document shall be referred to Commanding Officer, Naval Air Technical Services Facility, Defense Distribution Depot Susquehanna, PA, Bldg. 05, 5450 Carlisle Pike, Mechanicsburg, PA 17055-0789.

DESTRUCTION NOTICE — For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

ISSUED BY AUTHORITY OF THE CHIEF OF NAVAL OPERATIONS AND  
UNDER THE DIRECTION OF THE COMMANDER,  
NAVAL AIR SYSTEMS COMMAND.

THE AIRCRAFT	1
INDOCTRINATION	2
NORMAL PROCEDURES	3
FLIGHT CHARAC	4
EMER PROCEDURES	5
ALL-WEATHER OPERATION	6
COMM PROCEDURES	7
WEAPON SYSTEMS	8
FLT CREW COORD	9
NATOPS EVAL	10
PERFORM DATA	11
INDEX	12